

## MIDI Implementation Chart

**Name:** Muzykant 10

**Date:** 2009-05-04

**Producer:** Adam Śmiałek, [www.smialek.prv.pl](http://www.smialek.prv.pl)

**Version:** 1.0

|                     | Function                                                      | Transmitted                               | Recognized                                            | Remarks                                                                                                    |
|---------------------|---------------------------------------------------------------|-------------------------------------------|-------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| Basic Channel       | Default<br>Changed                                            | X<br>X                                    | 1,10,11,16<br>X                                       |                                                                                                            |
| Mode                | Default<br>Messages<br>Altered                                | X<br>X<br>*****                           | Mode 3<br>X<br>*****                                  |                                                                                                            |
| Note Number         | True Voice                                                    | 0-127<br>*****                            | 0-127<br>36,37,38,40,42,<br>46,49,51                  |                                                                                                            |
| Velocity            | Note ON<br>Note OFF                                           | X<br>X                                    | X<br>X                                                |                                                                                                            |
| Aftertouch          | Key's<br>Ch's                                                 | X<br>X                                    | X<br>0                                                |                                                                                                            |
| Pitch Bend          |                                                               | X                                         | 0                                                     | 7 bit<br>resolution                                                                                        |
| Control Change      | 1<br>2<br>64<br>66<br>67<br>71<br>72<br>73<br>74<br>75        | X<br>X<br>X<br>X<br>X<br>X<br>X<br>X<br>X | 0<br>0 0, 127<br>0<br>0<br>0<br>0<br>0<br>0<br>0<br>0 | Modulation<br>Breath<br>Sustain<br>Sostenuto<br>Soft<br>Timbre<br>Release<br>Attack<br>Brightness<br>Decay |
| Program Change      | True #                                                        | X<br>*****                                | 0<br>1-4                                              |                                                                                                            |
| System<br>Exclusive |                                                               | X                                         | X                                                     |                                                                                                            |
| System Common       | Song Pos<br>Song Sel<br>Tune                                  | X<br>X<br>X                               | X<br>X<br>X                                           |                                                                                                            |
| System Real<br>Time | Clock<br>Commands                                             | X<br>X                                    | X<br>X                                                |                                                                                                            |
| Aux Messages        | Local ON/OFF<br>All Notes OFF<br>Active Sense<br>System Reset | X<br>X<br>X<br>X                          | X<br>X<br>X<br>X                                      |                                                                                                            |
| Notes               |                                                               |                                           |                                                       |                                                                                                            |

Mode 1 : OMNI ON, POLY  
Mode 3 : OMNI OFF, POLY

Mode 2 : OMNI ON, MONO  
Mode 4 : OMNI OFF, MONO

0 : Yes  
X : No